




Spare parts list

Handheld pneumatic drills

CP 0069




Crowder Supply Co, Inc. 8495 Roslyn St Commerce City, CO 80022 (303) 433-5144 FAX: (303) 433-3928 Toll Free: (888) 883-5144 www.crowdersupply.com

www.cp.com

Chicago Pneumatic Construction Tools

Spare parts list

CP 0069 7/8" x 4 1/4"




Crowder Supply Co, Inc. 8495 Roslyn St Commerce City, CO 80022 (303) 433-5144 FAX: (303) 433-3928 Toll Free: (888) 883-5144 www.crowdersupply.com

| No. | Description | Remark | Quantity | Part number |
|-----------|--|-----------|----------|-------------|
| 1 | Bolt - Thru | | 2 | R085755 |
| 2 | Nut - Elastic stop | 5/8" - 11 | 3 | R005742 |
| 3 | Grip - Handle | | 2 | R075419 |
| 4 | Bracket - Handle | | 1 | R086608 |
| 5 | Liner - Handle | | 1 | R076172 |
| 6 | Washer - Handle bolt key | | 1 | R000142 |
| 7 | Bolt - Handle | | 1 | R076173 |
| 8 | Plug - Air tube | | 1 | R076793 |
| 9 | Gasket - Tube plug | | 2 | R000537 |
| 10 | Tube - Air | | 1 | R093907 |
| 11 | Washer - Air tube | | 1 | R095169 |
| 12 | Rubber - Air tube | | 1 | R090364 |
| 13 | Pin - Valve plunger | | 1 | R075802 |
| 14 | Plug - Water valve | | 1 | R076372 |
| 15(16-17) | Water valve port plug, complete | | 1 | R079130 |
| 16 | Water valve port plug | | 1 | |
| 17 | O-ring | | 1 | C079489 |
| 18(19-21) | Backhead, complete | | 1 | R137744 |
| 19 | Bushing - Water valve | | 1 | R098054 |
| 20 | Backhead | | 1 | |
| 21 | Bushing - Biow tube | | 1 | R137739 |
| 22 | Plug - Pipe | 1/2" | 2 | C068064 |
| 23 | Spring - Valve plunger | | 1 | R085671 |
| 24 | Plunger - Throttle valve | | 1 | R086627 |
| 25 | Plug - Pipe | 1/4" | 1 | C068799 |
| 26 | Nut - Hexagon | 1/2" - 20 | 1 | P002149 |
| 27 | Lock washer - Valve handle | 1/2" | 1 | C036717 |
| 28 | Handle - Throttle valve | | 1 | R079124 |
| 29 | Gasket | | 1 | H0980438 |
| 30 | Valve - Throttle | | 1 | R086628 |
| 31 | O-ring | | 1 | P103521 |
| 32 | Swivel - Air inlet | | 1 | R075265 |
| 33 | Screen - Air inlet | | 1 | R005584 |
| 34 | O-ring | | 1 | R110317 |
| 35 | Nut - Air inlet swivel | | 1 | R000530 |
| 36 | Pawl | | 4 | R075267 |
| 37 | Spring - Pawl | | 4 | R086654 |
| 38 | Bar - Rifle | | 1 | R093887 |
| 39 | Ring - Ratchet | | 1 | R137740 |
| 40 | Cover - Valve case | | 1 | R093490 |
| 41 | Pin - Dowel | | 1 | R137741 |
| 42 | Spacer - Valve case | | 1 | R085608 |
| 43 | Valve | | 1 | R093900 |
| 44 | Pin - Oiler | | 1 | R114133 |
| 45 | Case - Valve | | 1 | R085607 |
| 46 | Nut - Rifle bar | Steel | 1 | R075839 |
| 47 | Nut - Rifle bar | Bronze | 1 | R075826 |
| 48 | Piston | | 1 | R000126 |

| No. | Description | Remark | Quantity | Part number |
|-----------|------------------------|-----------------------------|----------|-------------|
| 49(50-51) | Cylinder, complete | | 1 | R137742 |
| 50 | Cylinder | | 1 | - |
| 51 | Bushing - Blower valve | | 1 | R085624 |
| 52 | Valve - Blower | | 1 | R085623 |
| 53 | Washer - Blower valve | | 1 | R075777 |
| 54 | Spring - Blower valve | | 1 | R075778 |
| 55 | Washer - Valve spring | | 1 | R075780 |
| 56 | Pin - Spring | | 1 | R076266 |
| 57(58-59) | Oil plug, complete | | 1 | R085611 |
| 58 | Gasket - Oil plug | | 1 | R091176 |
| 59 | Oil plug | | 1 | - |
| 60 | Bushing - Cylinder | | 1 | R137743 |
| 61 | Nut - Chuck rotation | | 1 | R086733 |
| 62 | Chuck | 7/8" x 4 1/4" (22 x 108 mm) | 1 | R093891 |
| 63 | Sleeve - Chuck | 7/8" x 4 1/4" (22 x 108 mm) | 1 | R041324 |
| 64 | Nut - Thru bolt | | 2 | R085756 |
| 65 | Fronthead | 7/8" x 4 1/4" (22 x 108 mm) | 1 | R041323 |
| 66 | Tunnion - Retainer | | 2 | R093896 |
| 67 | Buffer - Retainer | | 1 | R093897 |
| 68 | Retainer - Latch shoe | | 1 | R093898 |
| 69 | Retainer | 7/8" (22 mm) | 1 | R093913 |

CP 0069 WET 7/8" x 4 1/4"

Crowder Supply Co., Inc. 8495 Roslyn St Commerce City, CO 80022 (303) 433-5144 FAX: (303) 433-3928 Toll Free: (888) 883-5144 www.crowdersupply.com




Crowder Supply Co., Inc. 8495 Roslyn St Commerce City, CO 80022 (303) 433-3928 Toll Free: (888) 883-5144 www.crowdersupply.com

| No. | Description | Remark | Quantity | Part number |
|-----------|--|-----------|----------|-------------|
| 1 | Bolt - Thru | | 2 | R085755 |
| 2 | Nut - Elastic stop | 5/8" - 11 | 3 | R005742 |
| 3 | Grip - Handle | | 2 | R075419 |
| 4 | Bracket - Handle | | 1 | R086608 |
| 5 | Liner - Handle | | 1 | R076172 |
| 6 | Washer - Handle bolt key | | 1 | R000142 |
| 7 | Bolt - Handle | | 1 | R076173 |
| 8 | Plug - Air tube | | 1 | R076793 |
| 9 | Gasket - Tube plug | | 2 | R000537 |
| 10 | Washer - Air tube | | 1 | R095169 |
| 11 | Rubber - Air tube | | 1 | R090364 |
| 12 | Pin - Valve plunger | | 1 | R075802 |
| 13(14-15) | Water valve port plug, complete | | 1 | R079130 |
| 14 | Water valve port plug | | 1 | - |
| 15 | O-ring | | 1 | C079489 |
| 16(17-19) | Backhead, complete | | 1 | R137744 |
| 17 | Bushing - Water valve | | 1 | R098054 |
| 18 | Backhead | | 1 | - |
| 19 | Bushing - Blow tube | | 1 | R137739 |
| 20 | Plug - Pipe | 1/8" | 2 | C068064 |
| 21 | Spring - Valve plunger | | 1 | R085671 |
| 22 | Plunger - Throttle valve | | 1 | R086627 |
| 23 | Nut - Hexagon | 1/2" - 20 | 1 | P002149 |
| 24 | Lock washer - Valve handle | 1/2" | 1 | C036717 |
| 25 | Handle - Throttle valve | | 1 | R079124 |
| 26 | Gasket | | 1 | H0980438 |
| 27 | Valve - Throttle | | 1 | R086628 |
| 28 | O-ring | | 1 | P103521 |
| 29 | Swivel - Air inlet | | 1 | R075265 |
| 30 | Screen - Air inlet | | 1 | R005584 |
| 31 | O-ring | | 1 | R110317 |
| 32 | Nut - Air inlet swivel | | 1 | R000530 |
| 33 | Pawl | | 4 | R075267 |
| 34 | Spring - Pawl | | 4 | R086654 |
| 35 | Bar - Rifle | | 1 | R093887 |
| 36 | Ring - Ratchet | | 1 | R137740 |
| 37 | Cover - Valve case | | 1 | R093490 |
| 38 | Pin - Dowel | | 1 | R137741 |
| 39 | Spacer - Valve case | | 1 | R085608 |
| 40 | Valve | | 1 | R093900 |
| 41 | Pin - Oiler | | 1 | R114133 |
| 42 | Case - Valve | | 1 | R085607 |
| 43 | Nut - Rifle bar | Steel | 1 | R075839 |
| 44 | Nut - Rifle bar | Bronze | 1 | R075826 |
| 45 | Piston | | 1 | R000126 |
| 46(47-48) | Cylinder, complete | | 1 | R137742 |
| 47 | Cylinder | | 1 | - |
| 48 | Bushing - Blower valve | | 1 | R085624 |
| 49 | Valve - Blower | | 1 | R085623 |
| 50 | Washer - Blower valve | | 1 | R075777 |

| No. | Description | Remark | Quantity | Part number |
|-----------|---------------------------|-----------------------------|----------|-------------|
| 51 | Spring - Blower valve | | 1 | R075778 |
| 52 | Washer - Valve spring | | 1 | R075780 |
| 53 | Pin - Spring | | 1 | R076266 |
| 54(55-56) | Oil plug, complete | | 1 | R085611 |
| 55 | Gasket - Oil plug | | 1 | R091176 |
| 56 | Oil plug | | 1 | - |
| 57 | Bushing - Cylinder | | 1 | R137743 |
| 58 | Nut - Chuck rotation | | 1 | R086733 |
| 59 | Chuck | 7/8" x 4 1/4" (22 x 108 mm) | 1 | R093891 |
| 60 | Sleeve - Chuck | 7/8" x 4 1/4" (22 x 108 mm) | 1 | R041324 |
| 61 | Nut - Thru bolt | | 2 | R085756 |
| 62 | Fronthead | 7/8" x 4 1/4" (22 x 108 mm) | 1 | R041323 |
| 63 | Tunnion - Retainer | | 2 | R093896 |
| 64 | Buffer - Retainer | | 1 | R093897 |
| 65 | Retainer - Latch shoe | | 1 | R093898 |
| 66 | Retainer | 7/8" (22 mm) | 1 | R093913 |
| 67(68-80) | Water conversion, kit | | 1 | Z6544438 |
| 68 | Valve - Water | | 1 | - |
| 69 | Nipple - Hose | | 1 | - |
| 70 | Clamp - Punch lock | | 2 | - |
| 71 | Hose | 1/2" x 12" | 1 | - |
| 72 | Nut - Water inlet swivel | | 1 | - |
| 73 | Swivel - Water inlet | | 1 | - |
| 74 | Gasket - Swivel | | 1 | - |
| 75 | Retainer - Water strainer | | 1 | - |
| 76 | Strainer - Water | | 1 | - |
| 77 | Spud - Water inlet | | 1 | - |
| 78 | Tube - Water | | 1 | R093888 |
| 79 | O-ring | | 1 | C087316 |
| 80 | Plug - Blower port | | 1 | R085627 |

CP 0069 1" x 4 1/4"



Crowder Supply Co, Inc. 8495 Roslyn St Commerce City, CO 80022 (303) 433-5144 FAX: (303) 433-3928 Toll Free: (888) 883-5144 www.crowdersupply.com

| No. | Description | Remark | Quantity | Part number |
|-----------|--|-----------|----------|-------------|
| 1 | Bolt - Thru | | 2 | R085755 |
| 2 | Nut - Elastic stop | 5/8" - 11 | 3 | R005742 |
| 3 | Grip - Handle | | 2 | R075419 |
| 4 | Bracket - Handle | | 1 | R086608 |
| 5 | Liner - Handle | | 1 | R076172 |
| 6 | Washer - Handle bolt key | | 1 | R000142 |
| 7 | Bolt - Handle | | 1 | R076173 |
| 8 | Plug - Air tube | | 1 | R076793 |
| 9 | Gasket - Tube plug | | 2 | R000537 |
| 10 | Tube - Air | | 1 | R093907 |
| 11 | Washer - Air tube | | 1 | R095169 |
| 12 | Rubber - Air tube | | 1 | R090364 |
| 13 | Pin - Valve plunger | | 1 | R075802 |
| 14 | Plug - Water valve | | 1 | R076372 |
| 15(16-17) | Water valve port plug, complete | | 1 | R079130 |
| 16 | Water valve port plug | | 1 | - |
| 17 | O-ring | | 1 | C079489 |
| 18(19-21) | Backhead, complete | | 1 | R137744 |
| 19 | Bushing - Water valve | | 1 | R098054 |
| 20 | Backhead | | 1 | - |
| 21 | Bushing - Blow tube | | 1 | R137739 |
| 22 | Plug - Pipe | 1/8" | 2 | C068064 |
| 23 | Spring - Valve plunger | | 1 | R085671 |
| 24 | Plunger - Throttle valve | | 1 | R086627 |
| 25 | Plug - Pipe | 1/4" | 1 | C068799 |
| 26 | Nut - Hexagon | 1/2" - 20 | 1 | P002149 |
| 27 | Lock washer - Valve handle | 1/2" | 1 | C036717 |
| 28 | Handle - Throttle valve | | 1 | R079124 |
| 29 | Gasket | | 1 | H0980438 |
| 30 | Valve - Throttle | | 1 | R086628 |
| 31 | O-ring | | 1 | P103521 |
| 32 | Swivel - Air inlet | | 1 | R075265 |
| 33 | Screen - Air inlet | | 1 | R005584 |
| 34 | O-ring | | 1 | R110317 |
| 35 | Nut - Air inlet swivel | | 1 | R000530 |
| 36 | Pawl | | 4 | R075267 |
| 37 | Spring - Pawl | | 4 | R086654 |
| 38 | Bar - Rifle | | 1 | R093887 |
| 39 | Ring - Ratchet | | 1 | R137740 |
| 40 | Cover - Valve case | | 1 | R093490 |
| 41 | Pin - Dowel | | 1 | R137741 |
| 42 | Spacer - Valve case | | 1 | R085608 |
| 43 | Valve | | 1 | R093900 |
| 44 | Pin - Oiler | | 1 | R114133 |
| 45 | Case - Valve | | 1 | R085607 |
| 46 | Nut - Rifle bar | Steel | 1 | R075839 |
| 47 | Nut - Rifle bar | Bronze | 1 | R075826 |
| 48 | Piston | | 1 | R000126 |



| No. | Description | Remark | Quantity | Part number |
|-----------|------------------------|---------------------------|----------|-------------|
| 49(50-51) | Cylinder, complete | | 1 | R137742 |
| 50 | Cylinder | | 1 | - |
| 51 | Bushing - Blower valve | | 1 | R085624 |
| 52 | Valve - Blower | | 1 | R085623 |
| 53 | Washer - Blower valve | | 1 | R075777 |
| 54 | Spring - Blower valve | | 1 | R075778 |
| 55 | Washer - Valve spring | | 1 | R075780 |
| 56 | Pin - Spring | | 1 | R076266 |
| 57(58-59) | Oil plug, complete | | 1 | R085611 |
| 58 | Gasket - Oil plug | | 1 | R091176 |
| 59 | Oil plug | | 1 | - |
| 60 | Bushing - Cylinder | | 1 | R137743 |
| 61 | Nut - Chuck rotation | | 1 | R086733 |
| 62 | Chuck | 1" x 4 1/4" (25 x 108 mm) | 1 | R093890 |
| 63 | Sleeve - Chuck | 1" x 4 1/4" (25 x 108 mm) | 1 | R041324 |
| 64 | Nut - Thru bolt | | 2 | R085756 |
| 65 | Fronthead | 1" x 4 1/4" (25 x 108 mm) | 1 | R041323 |
| 66 | Tunnion - Retainer | | 2 | R093896 |
| 67 | Buffer - Retainer | | 1 | R093897 |
| 68 | Retainer - Latch shoe | | 1 | R093898 |
| 69 | Retainer | 1" (25 mm) | 1 | R093895 |



Accessories


Accessories

| Description | Remark | Quantity | Part number |
|-----------------|--------------------------------------|----------|--------------|
| Water separator | European version, BSP | 1 | 8900 0050 00 |
| Water separator | US version, NPT | 1 | 8900 0050 01 |
| Lubricator 43 | US version claw couplings, NPT | 1 | 8900 0050 07 |
| Lubricator 1300 | European version claw couplings, BSP | 1 | 8900 0050 02 |
| RED-X, Air hose | Pre-mounted US 50 ft (15 m) | 1 | 8900 0050 08 |
| RED-X, Air hose | Pre-mounted 20 m (65 ft) | 1 | 8900 0050 09 |
| RED-X, Air hose | 60 m (195 ft) | 1 | 8900 0050 10 |

Crowder Supply Co, Inc. 8495 Roslyn St Commerce City, CO 80022 (303) 433-5144 FAX: (303) 433-3928 Toll Free: (888) 883-5144 www.crowdersupply.com

Kits

Water conversion kit



| No. | Description | Remark | Quantity | Part number |
|---------|---------------------------|------------|----------|-------------|
| 1(2-14) | Water conversion kit | | 1 | Z6544438 |
| 2 | Valve - Water | | 1 | - |
| 3 | Nipple - Hose | | 1 | - |
| 4 | Clamp - Punch lock | | 2 | - |
| 5 | Hose | 1/2" x 12" | 1 | - |
| 6 | Nut - Water inlet swivel | | 1 | - |
| 7 | Swivel - Water inlet | | 1 | - |
| 8 | Gasket - Swivel | | 1 | - |
| 9 | Retainer - Water strainer | | 1 | - |
| 10 | Strainer - Water | | 1 | - |
| 11 | Spud - Water inlet | | 1 | - |
| 12 | Tube - Water | | 1 | R093888 |
| 13 | O-ring | | 1 | C087316 |
| 14 | Plug - Blower port | | 1 | R085627 |