

MODEL JET-06

JET EQUIPMENT TOOLS

BACKFILL TAMPER

CROWDER SUPPLY CO., INC. - 8495 ROSLYN ST. - COMMERCE CITY, CO 80022 - TOLL FREE 888-883-5144 - www.crowdersupply.com

SYM. NO.	PART NO.	CONTINENTAL NO.	DESCRIPTION	AMT. REQ.
1	JET06-01	6501	Handle	1
	JET06-01A	6500	Handle Assembly Complete	1
2	JET06-02	6503	Handle Lever	1
3	JET06-03	6504	Handle Lever Pin (6 x 22)	1
4	JET06-04	6505	Handle Lever Ring	1
5	JET06-05	6502	Throttle Valve Bushing	1
6	JET06-06	6506	Throttle Valve	1
7	JET06-07	6510	O-Ring (P-22)	1
8	JET06-08	6508	Throttle Valve Spring	1
9	JET06-09	6509	Throttle Valve Spring Plug	1
10	JET06-10	6512	Connecting Pipe (NPT 3/4)	1
11	JET06-11	6514	Connecting Pipe Lock Nut	1
12	JET06-12	6516	Cylinder Cap (NPT 3/4)	1
13	JET06-13	6517	Oil Plug (GDL NPTF 1/4)	1
14	JET06-14	6511	Cylinder Cap Bushing	1
15	JET06-15	6515	Valve Housing Bushing	1
16	JET06-16	6522	Upper Valve Plate	1
17	JET06-17	6525	Lower Valve Plate	1
18	JET06-18	6518	O-Ring (P-32)	1
19	JET06-19	6523	Center Valve Plate	1
20	JET06-20	6524	Automatic Valve	1
21	JET06-21	6526	Valve Knock Pin	2
22	JET06-22	6527	Cylinder	1
23	JET06-23	6528	Exhaust Deflector	1
24	JET06-24	6531	Upper Guide Bushing	1
25	JET06-25	6532	O-Ring (P-35)	2
26	JET06-26	6533	Packing (Upper)	1
27	JET06-27	6533	Packing (Middle)	1
28	JET06-28	6533	Packing (Lower)	1
29	JET06-29	6535	Lower Guide Bushing	1
30	JET06-30	6537	Packing Nut	1
31	JET06-31	6536	Lock Ring Stuffing Box	1
32	JET06-32	6530	Piston	1
33	JET06-33	9538	Butt (Hollow Steel) Ref. 556630	1
34	JET06-34	6540	Clamp Screw	1
35	JET06-35	6507	O-Ring (P-10)	1

