

JET EQUIPMENT TOOLS

MODEL PB-40

PAVING BREAKER

SYM. NO.	PART NO.	CONTINENTAL NO.	DESCRIPTION	AMT. REQ.
1	PB40-01	6401	Cylinder	1
3	PB40-03	6403	Piston Hammer	1
4	PB40-04	6404	Valve	1
5	PB40-05	6405	Valve Chest	1
6	PB40-06	6406	Valve Chest O-Ring, Small	1
7	PB40-07	6407	Valve Cover	1
8	PB40-08	6408	Valve Chest O-Ring, Large	1
10	PB40-10	6410	Coned Disc Spring	1
11	PB40-11	6411	Back Head (re: PB40-11CP)	1
	PB40-11CP	6411-C	Back Head Complete	1
13	PB40-13	6613	Rubber Grip	2
14	PB40-14	6414	Throttle Push Rod	1
15	PB40-15	6415	Throttle Valve Bushing	1
16	PB40-16	6416	Throttle Valve Spring	1
17	PB40-17	6617	Throttle Valve	1
18	PB40-18	6618	Throttle Lever Pin	2
21	PB40-21	6421	Front Head	1
23	PB40-23	6323	Back Head Bolt	4
24	PB40-24	6324	Back Head Bolt Lock Washer	4
25	PB40-25	6325	Back Head Bolt Nut	4
28	PB40-28	6628	Steel Retainer	1
29	PB40-29	6629	Steel Retainer Bolt	1
30	PB40-30	6630	Steel Retainer Bolt Nut	1
31	PB40-31	6631	Steel Retainer Bolt Nut Washer	1
32	PB40-32	6632-A	Steel Retainer Bolt Bushing	2
33	PB40-33	6633	Steel Retainer Plunger	1
34	PB40-34	6634	Steel Retainer Spring	1
35	PB40-35	6435	Air Inlet Swivel	1
35B	PB40-35B	6446	Air Inlet Swivel O-Ring	1
36	PB40-36	6436	Air Inlet Swivel Nut	1
37	PB40-37	6437	Air Inlet O-Ring	1
38	PB40-38	6438	Air Inlet Screen	1
38B	PB40-38B	6447	Air Inlet Swivel Spacer	1
39	PB40-39	6339	Front Head Bolt	1
40	PB40-40	6340	Front Head Bolt Nut	1
44	PB40-44	6444	Front Head Bushing (1")	1
46	SB-3/4	6448	Throttle Valve Ball	1
48	PB40-48	6412	Throttle Push Rod O-Ring	1
55	PB40-55	6449	Screw Bushing	1
56	550051	6482	Muffler CP.	(1)

