

MODEL PB-60

JET EQUIPMENT TOOLS

PAVING BREAKER

CROWDER SUPPLY CO., INC. - 8495 ROSLYN ST. - COMMERCE CITY, CO 80022 - TOLL FREE 888-883-5144 - www.crowdersupply.com

SYM. NO.	PART NO.	CONTINENTAL NO.	DESCRIPTION	AMT. REQ.
1	PB60-01	6601	Cylinder	1
2	PB90-02	6602	Cylinder Plug	3
3	PB60-03	6603	Piston Hammer	1
4	PB90-04	6604	Automatic Valve	1
5	PB60-05	6605	Valve Chest	1
6	PB60-06	6606	Valve Seat	1
7	PB60-07	6607	Valve Guide	1
8	PB90-08	6608	Valve Chest Dowel Pin	1
9	PB90-09	6609	Plunger	1
10	PB90-10	6610	Plunger Spring	1
11	PB60-11	6611	Back Head (Bare)	1
12	PB90-12	6612	Back Head Port Seal O-Ring	1
13	PB90-13	6613	Rubber Grip	2
14	PB90-14	6614	Throttle Valve	1
15	PB90-15	6615	Throttle Valve Stem Guide	1
16	PB90-16	6616	Throttle Valve Spring	1
17	PB90-17	6617	Throttle Lever	1
18	PB90-18	6618	Throttle Lever Pin	2
19	PB60-19	6619	Oil Plug	1
20	PB90-20	6620	Oil Control Plug Hex. PT (5/8")	1
21	PB60-21	6621	Front Head	1
23	PB60-23	6623	Back Head Bolt	4
24	PB90-24	6624	Back Head Bolt Lock Washer (5/8")	4
25	PB90-25	6625	Back Head Bolt Nut	4
26	PB60-26	6626	Tappet Seat	1
27	PB60-27	6627	Tappet	1
28	PB90-28	6628	Steel Retainer	1
29	PB90-29	6629	Steel Retainer Bolt	1
30	PB90-30	6630	Steel Retainer Bolt Nut	1
31	PB90-31	6631	Steel Retainer Washer (5/8")	1
32	PB90-32	6632-A	Steel Retainer Bolt Bushing	2
33	PB90-33	6633	Steel Retainer Plunger	1
34	PB90-34	6634	Steel Retainer Spring	1
35A	PB60-35	6035	Air Inlet Swivel	1
35B	PB60-35B	6050	Air Inlet O-Ring	1
36	PB90-36	6036	Air Inlet Swivel Nut	1
37	PB90-37	6037	Air Inlet Swivel O-Ring	1
38	PB90-38	6038	Air Inlet Screen	1
39	PB60-39	6639	Front Head Bolt	2
40	PB90-40	6640	Front Head Bolt Nut	2
41	PB90-41	6641	Lock Washer (3/4")	2
42	PB90-42	6642	Front Head Bolt Spring	2
43	PB60-43A	6644-A	Front Head Bushing (1-1/8")	1
	PB90-43B	6644-B	Front Head Bushing (1-1/4")	(1)
45	PB90-45	6645	Felt Oiler	1
46	550061	6682	Muffler CP.	(1)
50	PB90-50	6053	Spring Pin	1
51	PB90-51	6054	Stop Lever	1
52	PB90-52	6055	Stop lever Spring	1

