

TTMA Flange Extensions

Flange extensions are used on load arms to connect the API load coupler to the load arm.

- adds a 6" space between the load arm and the tank truck
- Flange extension with groove provides a specified parting point to prevent excessive damage to the loading arm.

Size	Description	Aluminum	
		Part #	Price/E
4"	TTMA flange extension	TETF4AL	\$127.00
4"	TTMA flange extension with groove	TETFG4AL	132.00



TETF4AL



TETFG4AL

Type 35 Loading Arm Swivel

- TTMA loading arm swivel with D style shovel handle
- TTMA flanges on both ends
- shovel handle is used to guide the API load coupler onto the adapter on the tank truck
- long radius elbow improves the flow into the API load coupler and provides spacing between the load arm and the tank truck
- can be used with flange extensions above



style 40

Size	Description	Aluminum	
		Part #	Price/E
4"	style 44H tank truck x Buna tank truck flange	44HTFXTFAL00000	\$1400.00
4"	style 44H tank truck x Viton® tank truck flange	44HTFXTFAL11000	1400.00
4"	style 30 tank truck x Buna tank truck flange	43HTFXTFAL00000	1200.00
4"	style 30 tank truck x Viton® tank truck flange	43HTFXTFAL11000	1200.00



style 30

Type 35 Loading Arm Swivel Replacement Parts

- two repair kits are required for style 50

Size	Description	Part #	Price/E
4"	aluminum nipple	ATN100x7	\$20.00
	D style shovel handle	100DHAN-AL	30.80
	Buna repair kit	4RKOBU	35.00
	Viton® repair kit	4RKOVIVI	53.00